

CODING A 433MHz REMOTE CONTROL INTO EASYLIFTER SECTIONAL OPENER

CODING REMOTE FROM THE OPENER



The opener can only be operated from remote controllers that have been programmed into its memory.

STEP ONE



Press and
HOLD

STEP TWO

Press
and release
the "Learn"
button on
opener



STEP THREE



The light will flash
when coded

OR

(if no light)
2 clicks will sound



RELEASE



Then, press
to test

CHANGING A BATTERY



Battery Type: 1 x 12V A23.

STEP ONE



Check Light
Status Table



HOLD

Light Status

Battery

Solid

OK

Flashing

Replace

No light

Replace

STEP TWO



Slide back
cover down to
expose battery

STEP THREE



Replace battery and slide
cover back into position



WARNING!: The battery is hazardous and must be kept out of reach of children. The battery can cause severe or fatal injuries if swallowed or placed inside any part of the body. If you suspect the battery has been swallowed or placed inside any part of the body, SEEK IMMEDIATE medical attention.