


## 1.0 lock position status

The status normally displays for 10secs after lock movement / button press.

### LED Status Indicators

| RED                    | GREEN                  | LOCK STATUS              |
|------------------------|------------------------|--------------------------|
| FLASHING RAPIDLY       |                        | LOCKING                  |
| ON                     |                        | LOCKED                   |
|                        | FLASHING RAPIDLY       | UNLOCKING                |
|                        | ON                     | UNLOCKED                 |
| ON                     | ON                     | ERROR                    |
| FLASHING SLOWLY        | FLASHING SLOWLY        | LOW BATTERY              |
| FLASHING ALTERNATIVELY | FLASHING ALTERNATIVELY | NO LINK WITH BASESTATION |

## 2.0 manual lock operation



### 2.1 To Disengage the Autolock:

Press the emergency lock/unlock button on the front of the Auto-Lock to disengage the locking bolt from the guide track and allow you to disengage the opener and open the door.



**WARNING! The emergency lock/unlock button on this product is not to be used as a primary means of locking the door under normal circumstances.**


### 2.2 Use of the Lock/Unlock Button:

The emergency lock/unlock button is to be used only in case of power outage or emergency.

## 3.0 battery replacement

Battery Type: 2 x C-LR 14.

1. Replace lock batteries (2 x C-LR 14) immediately when the Auto-lock LED's red and green lights flash 3 times or are flashing slowly.
2. Remove cover by unscrewing the four screws on the main cover.



3. Replace batteries and refit cover and secure with screws.
4. Test the Auto-lock operation by using the opener to open and close the door.

## 4.0 smart phone control (optional)

The Smart Phone Control works via your home's WiFi network. Initial set up involves linking your phone app and smart opener to your home network.

1. Download the B&D App.
2. Remove the controls cover on opener to access the buttons.
3. Ensure the WiFi router is within range of the opener.
4. Open the App and click Get Started.
5. Follow the on screen in app setup instructions.
6. Upon completion, refit the controls cover and test the opener operation through your app.

When connected you can view the operation of your Autolock and the App will send you notifications when issues arise.

## 5.0 troubleshooting

| Symptom   | Possible cause                                      | Remedy  |
|---|---|---|
| main light flashes 3 times on the opener            | low battery indicator                               | change battery, then test operation of lock by pressing the lock / unlock button.   |
| door not moving and no lights on lock               | limited battery power                               | press the (i) button on the lock to see if there is power in the battery.<br>no lights - change battery<br>lights - check LED status table.   |
| main light flashes 5 times                          | lock is not unlocked and preventing the door moving | check lock, test by pressing lock/ unlock button. If it does not move call 13 62 63.  |
| lock is not unlocking and preventing doors movement | lock jammed   | check if there is anything obstructing the lock bolt movement. Press the unlock button on each lock. If it does not move call 13 62 63.   |
| red and green lights both on solid on the lock.     | error with lock                                     | press the unlock button on the lock to test operation.<br>switch off power to opener, then switch back on after 30 secs (If a battery backup is installed press & hold STOP/SET button on the opener until power ceases). Press the lock/ unlock button on the lock to test operation. If it does not move call 13 62 63. |
| red and green lights on one lock flashing slowly    | low battery   | change battery, then test operation of lock by pressing the lock / unlock button.   |
| red and green lights flashing alternatively         | no link to opener                                   | press the unlock button on the lock with flashing lights to disengage the bolt. Call 13 62 63 for assistance.   |

## 6.0 caring for your Autolock

Preventative servicing of your garage door, opener and autolock, is important. Your autolock is made up of numerous moving parts designed to lock your door every time you close it.

Ongoing care ensures that your door continues to function within factory specifications, greatly reduces the risk of failure and repair bills down the track and ensures you maintain your Warranty.

If the Autolock is located in a very dirty / dusty environment, be sure to vacuum any residue from the lock and bolt before continuing use.



**WARNING! Do not use water, benzene or alcohol when cleaning the product, as these fluids can cause product malfunction.**

## 7.0 need a service call?

If the opener needs a service please call the dealer who installed the garage door opener (their contact details are usually on a sticker on the back of your garage door).



SCAN: for Installation Instructions

For product assistance, general enquiry or more information, please visit:

**bnd.com.au**  
or call **13 62 63.**